



MANUAL HEAVEN TOUCH™



SPECIFICATION

1. Power/Vibration/Extension Button: Press and hold for 1.5 seconds to turn the device on or off. Once in standby mode, a short press will activate Vibration + Extension Mode 1: pressing it continuously will cycle through 10 Vibration + Extension modes and then restart from the first mode.
2. Suction Button: When the device is powered on, a short press activates Suction Mode 1, and pressing and holding for 1.5 seconds turns off the suction mode.
3. Heating Button: When the device is powered on, a short press turns the heating mode on or off.
4. When charging, the white indicator light will "breathe" (slowly fade in and out) and the motor will vibrate once to indicate entry into the charging state. The light will stay on steadily when fully charged, and the device will not function during charging.

-  Heating button
-  Power / Vibration / Extension button
-  Suction button



CHARGING INSTRUCTION

Connect the magnetic charging cable to the charging port, then plug the power supply into a power source.

The indicator light will begin to flash steadily, indicating that charging has started.

Power Indicator  once charging is complete, the indicator light will remain solid.

- Important :
- ◆ Please turn off the device before charging, then connect the magnetic charging cable.
 - ◆ When plugging in or unplugging the charging cable, ensure that your hands are dry.
 - ◆ For the first charge, the recommended charging time is approximately 135 minutes.
 - ◆ The device cannot be turned on or used while charging.

CLEANING & STORAGE

- ◆ Please clean the vibrator before & after each use.
- ◆ Wash with warm water and soap, suggest to add detergent specialized for sextoys, disinfectant or 70% alcohol(long term use of alcohol is not suggested because alcohol will corrode the appearance of the product so as to shorten its life).
- ◆ Pat dry with a cotton towel and allow to air dry completely.
- ◆ Please storage in dust-free place and with no other material.
- ◆ Keep it out reach of children.

SAFETY

As an intimate partner of user. It's common duty to use this product safely and healthy for both customers and us. Thus we remind our customers as below:

- ◆ This product is for personal use, please do not share with others for your health.
- ◆ This product has several function modes. Please stop using if feeling discomfort or allergy.
- ◆ For your health, please do not use while you are in illness, period or injury.
- ◆ Suggest to use with lubricant to get better experience. Please stop using if the surface is not smooth or with sharp corners.

AFTER SALE SERVICE

We provide 12 months manufacturer warranty. If any quality problem happen during this period, please contact us to get efficient and high quality service.



Body-safe silicone



Mute



Rechargeable



Waterproof



Easy to carry

Warning:
This product is for over
18 years old adult only