



MANUAL PEARL WHISPER™



SPECIFICATION

Name: Pearl Whisper
Type: Automatic Female Masturbator
Mode: D18A
Material: ABS+TPE
Voltage: ≤ 3.7
Current: $\leq 200\text{mA}$
Noise: $\leq 60\text{DB}$
Weight: 145g
Size: 80*60mm
Power: Lithium Battery
Package: Machine x1, Charging Cable x1, Manual x1
Target: Adults

Selection of Lubricant

Please use water-soluble human body lubricants. In order to ensure product safety, do not use it with silicone-based lubricants. Silicone-based lubricants will corrode silicone products.

CHARGING INSTRUCTION



Free USB charging cable, support various mobile phone chargers and laptops, more convenient to carry.

1. Please fully charge the appliance before using it for the first time.
2. Please clean and dry the appliance thoroughly before each charge.

3. Connect the USB cable to a USB power adapter (not including this accessory) or USB port, you can use any USB power adapter for charging.

4. It takes 3 hours for a full charge. The specific charging time may vary according to the amount of residual power inside the appliance.

5. The use time of this appliance can be up to 60 minutes after it is fully charged. The use time of this appliance depends on the working mode you choose. The higher the frequency of the working mode, the faster the battery consumption.

6. There is no need to completely exhaust the battery before charging.

7. In order to prolong the battery life and ensure the charging effect, we recommend that you charge the appliance before the sucking power is significantly weakened.

8. Before discarding the appliance, the battery must be removed from the appliance. When removing the battery, the appliance must be powered off and the battery should be disposed of safely.

CLEANING & STORAGE

- ◆ Please clean the vibrator before & after each use.
- ◆ Wash with warm water and soap, suggest to add detergent specialized for sextoys, disinfectant or 70% alcohol (long term use of alcohol is not suggested because alcohol will corrode the appearance of the product so as to shorten its life).
- ◆ Pat dry with a cotton towel and allow to air dry completely.
- ◆ Please storage in dust-free place and with no other material.
- ◆ Keep it out reach of children.

SAFETY

As an intimate partner of user. It's common duty to use this product safely and healthy for both customers and us.
Thus we remind our customers as below:

- ◆ This product is for personal use, please do not share with others for your health.
- ◆ This product has several function modes. Please stop using if feeling discomfort or allergy.
- ◆ For your health, please do not use while you are in illness, period or injury.
- ◆ Suggest to use with lubricant to get better experience. Please stop using if the surface is not smooth or with sharp corners.

AFTER SALE SERVICE

We provide 12 months manufacturer warranty. If any quality problem happen during this period, please contact us to get efficient and high quality service.



Body-safe silicone



Mute



Rechargeable



Waterproof



Easy to carry

Warning:
This product is for over
18 years old adult only