



MANUAL SERICA™



SPECIFICATION

Material : Silicone+ABS
Size: 104x38x182 mm
Mode: 10 modes Vibration +Thrusting +Digging +Rotation
Charge time: 120-150 Mins
Using time: ≥60 Mins
Waterproof: IPX6

1. 10 modes of vibration
2. Made of safe silicone, soft and comfortable
3. Quiet design, protecting your privacy
4. The 10 vibration modes at the simple touch of a button and enjoy those deeply gratifying internal sensations.



 Vibration button
10 Vibration modes

 Power button

INSTRUCTION

- ◆ Turn ON/OFF:
Press and hold  button for 1.5 seconds.
- ◆ Switch A Head Frequency Settings:
Quickly press  button to switch A head vibration, thrusting and digging frequency cycle.
Double-click the  to pause A head vibration, thrusting and digging function.
- ◆ Switch B Head Frequency Settings:
Quickly press  button to switch B head vibration and rotation frequency cycle;
Double-click the  to pause B head vibration & rotation function.
- ◆ FLASHING Light : Charging
SOLID Light : Fully Charged.
- ◆ Low Battery Reminder
The light flashes quickly until it's turned off.

CLEANING & STORAGE

- ◆ Please clean the vibrator before & after each use.
- ◆ Wash with warm water and soap, suggest to add detergent specialized for sextoys, disinfectant or 70% alcohol(long term use of alcohol is not suggested because alcohol will corrode the appearance of the product so as to shorten its life).
- ◆ Pat dry with a cotton towel and allow to air dry completely.
- ◆ Please storage in dust-free place and with no other material.
- ◆ Keep it out reach of children.

SAFETY

As an intimate partner of user. It's common duty to use this product safely and healthy for both customers and us.
Thus we remind our customers as below:

- ◆ This product is for personal use, please do not share with others for your health.
- ◆ This product has several function modes. Please stop using if feeling discomfort or allergy.
- ◆ For your health, please do not use while you are in illness, period or injury.
- ◆ Suggest to use with lubricant to get better experience. Please stop using if the surface is not smooth or with sharp corners.

AFTER SALE SERVICE

We provide 12 months manufacturer warranty. If any quality problem happen during this period, please contact us to get efficient and high quality service.



Body-safe silicone



Mute



Rechargeable



Waterproof



Easy to carry

Warning:
This product is for over
18 years old adult only